

**USE & CARE**  
**BOING**

# BO!NG WASHBASINS: USE AND CARE GUIDE

# BO!NG

SOFT  
COLOURFUL  
WARM  
FUN



BO!NG washbasins are manufactured in flexible polyurethane. This is an inert material suitable for the bathroom environment used in the conventional way.

Being warm, flexible and colorful, they are ideal for children's or courtesy bathrooms, at home and in public toilets.

Their surface is smooth and impermeable, with a slight porosity close to 2%, the same as some natural stone materials or mineral resins.

It is important to follow the recommendations in this Guide.

Enjoy them!

## RECOMMENDATIONS FOR USE AND CLEANING

No special maintenance needed, can be cleaned with any product suitable for cleaning sanitation and rinsed with water. We recommend using a sponge or damp cloth. Avoid scouring pads.

If accidentally a stain is produced which, is resistant to soap, we recommend dabbing with clean cotton and bleach, nail polish remover or ethyl alcohol of 96 ° and washing again with water

It is advisable to avoid using unsuitable chemicals \* or extremely aggressive, strong acids or certain organic solvents. In case of an occasional spill of any of these, rinse quickly without leaving the chemical for any length of time on the washbasin, as that can cause stains, discoloration or deterioration of the surface. (\* refer [www.boingoriginal.com](http://www.boingoriginal.com)).

Before using a product on the washbasin, you should read the label carefully and test with a small application on an inconspicuous part of the sink.

## SPECIAL PRECAUTIONS

**ATTENTION!** Some cosmetic products, products for writing, drawing or painting and some food products, can leave stains if left uncleaned for a time.

**Such staining usually disappears entirely if cleaned with nail polish remover or ethyl alcohol of 96 °. A coffee stain is completely removed with bleach.**

**DANGER!** Hair dyes, some markers, pens or pencils, shoe polishes and some food spices, like saffron, curry and mustard often leave permanent stains that can not be eliminated completely.

**These stains can only reduce intensity with certain organic solvents or products containing them, such as nail polish remover, ethyl alcohol, turpentine, gasoline, etc.. and sometimes with bleach.**

**DANGER!** Some very aggressive cleaning products, such as Salfuman or certain drain cleaning agents, left in contact unwashed for days, can damage the surface causing roughness, coarseness or discoloration.

**Don't leave cigarettes or electrical appliances which, support high temperatures on the washbasins. They can irreversibly damage the surface.**

**Certain strong fast paste adhesives are difficult to eliminate without damaging the surface of the sink.**

**[www.boingoriginal.com](http://www.boingoriginal.com)**

Plaza Mossén Milà 1-1 46003 VALENCIA <ESPAÑA>  
TEL <0034> 963 153 800 - FAX <0034> 963 910 473